

# BATTERY TEST AND CODE READER TOOL

BST580D features 5 battery test modes, including Battery Health State Test, Voltage Test, Ripple Test, Starting System Test and Charging System Test. The battery test voltage ranges from 10V to 16V.



• NEW

10 BATTERY STANDARDS  
CCA/BCI/CA/MCA/JIS/DIN/IEC/EN/SAE/GB

3 BATTERY TYPES  
LEAD-ACID/GEL/AGM



Battery health state test




Voltage test



Ripple detection



Starting system test



Charging system test

## FEATURES

- Full OBDII functionalities are supported.
- I/M Quick Scan via the physical shortcut on the 2.8" screen.
- DTC Lookup & Definition via the physical shortcut on the 2.8" screen.
- Battery test report review is supported.
- 7 foreign languages are supported: English, Spanish, French, German, Russian, Portuguese, Japanese.
- Data reports are printed via USB cable.
- Lifetime FREE software update.

## SPECIFICATION

DISPLAY	2.8", 320*240
RAM	3 MB
STORAGE	16 MB
BATTERY TEST VOLTAGE	10V - 16V
WORK TEMPERATURE	0~50°C
DIMENSION	179*103*30 (mm)